

Required Details

- EUVI
 - Normal
 - SC, FW, WL, FPS, IPT, ExpT, CamT
 - Double
 - SC, FW, WL, WL, FPS, IPT, ExpT, CamT
 - Dark
 - SC, FPS, IPT, CamT, ExpTime (0:99998ms)
 - LED
 - SC, FW, WL, FPS, IPT, CamT, Pulse (1-3300000), Color
 - Continuous
 - SC, FW, WL, FPS, IPT, CamT
 - Sequence (n=2-4)
 - SC, FW, WL*n, FPS, IPT, ExpT, CamT, Cadence (0=close-as-possible)

Required Details

- COR1 ad COR2
 - Normal
 - SC, Polar, IPT, ExpT, CamT
 - Double
 - SC, Polar, Polar, IPT, ExpT, CamT
 - Dark
 - SC, IPT, CamT, ExpTime (0:99998ms)
 - LED
 - SC, Polar, IPT, CamT, Pulse (1-3300000), Color
 - Continuous
 - SC, Polar, IPT, CamT
 - Sequence (n=2-4)
 - SC, Polar*n, IPT, ExpT, CamT, Cadence (0=close-as-possible)

Required Details

- HI-1 and HI-2
 - Normal
 - SC, IPT, ExpT, CamT
 - Dark
 - SC, IPT, CamT, ExpTime (0:99998ms)
 - LED
 - SC, IPT, CamT, Pulse (1-4300000), Color
 - Continuous
 - SC, IPT, CamT
 - Sequence (n=2-99)
 - SC, IPT, ExpT, CamT, Cadence (0=close-as-possible)

An Example

- Scientist requests
 - ♦ Full field EUVI images on SC-A every 2-hrs
 - ♦ S1 FilterWheel, 284A, 1 sec exposure
- SECCHI planner requires
 - ♦ SC-A, EUVI, Normal, FW=S1, Wave=284, FPS=Off, IPT=0, ExpT=6, CamT=1, Cadence=120min
 - ♦ Where...
 - IPTbl 0 >> SSR1, Rice Compressed
 - EXPTbl 6 >> 1.0 Second exposure
 - CamTbl 1 >> 2176x2048, no CCD summing, Hi gain